Part List

Part A Qty 2 (Bed Heads Rails)

Part B Qty 2 (Bed Side Rails)


Part C Qty 4 (Top Corner)

Part D Qty 8 (2-1/4 Machine Screws)


Part E Qty 4 (Bottom Corner)

Part F Qty 8 (Wing Nuts)

Picture of Parts



Step One: Place Mat black rubber side with wood up. Slide Part A with *black letter facing up* on to short end of Mat. Like shown in pictures below.



Slide second Part A on opposite end. Mat should look like this.



Step Two: Slide both part B on long ends of mat. Mat should look like this.



Step Three: Slid Screws, part D through holes of part C.



Step Four: Align part C with screws with holes in corner of bed.



Repeat Step four on all corners before doing step five, or the PVC may not slid into place.

Step Five: Align part E over screws on each corner.



Step Six: Place wing nuts Part F on all screws and hand tighten them.

Step Seven: Place legs in upward facing holes, with black lettering facing the center of bed.



Step Eight: Turn bed over and tighten all screws. Use a either a Philips or flat head screw driver to tighten all screws while holding the wing nuts on other side. If using a power screw driver be carful not to over tighten.

Berker's Dog Beds



www.BerkersDogBeds.Com

Because every dog deserves a bed!

How to put together your Peluche Tough Kennel Bed.